

Comments
— or —
Questions?

CALL US!

EganCabinet

INSTALLATION

WARRANTY

Egan Visual Inc. warrants the frame construction and finish of this product for normal and reasonable use for the period of five (5) years from the date of invoice. This warranty does not apply to defects resulting from lack of normal maintenance, improper cleaning or negligence.

CANADA: 1-800-263-2387
USA EAST: 1-800-263-2387
USA WEST: 1-800-826-1778

email: installations@egan.com
www.egan.com

Reference #024H220 rev 2-10/02:PDF

©Egan Visual, Inc. 2000



The Leader in Visual Systems
...and more



The Leader in Visual Systems
...and more



The Leader in Visual Systems
...and more

TOOLS REQUIRED:

**Tape Measure, Level,
Electric Drill, 1/4" Drill bit**

Installer to provide fastening hardware best suited to wall type and cabinet weight. Hollow wall toggle bolts illustrated.

PICTURE A

1. Locate the bottom of the supplied mounting bracket 72" from the floor.
2. Level and mark the bracket position.
3. Drill two holes on mounting bracket 6" in from either end as illustrated.

CAUTION: *Ceilings and floors may not always be completely parallel, so adjust bracket level accordingly if necessary.*

PICTURE B

4. Mark and drill mounting holes in wall using positioned bracket as a guide.
5. Place fastener through bracket, attach toggle end and feed through wall.
6. Secure the toggle bolts. Pull bracket away from wall while tightening. Other fasteners may differ.

PICTURE C

7. Place cabinet onto mounting bracket and slide down to lock into position.
8. If wall is not true shims are necessary to allow doors to close properly.

PICTURE D

Additional safety brackets are located in the pentray to avoid cabinet from being lifted up and off bracket.

10. Flip-down bracket and mark hole locations on pen tray backing.
11. Flip-up bracket and drill for appropriate wall screws.
12. Flip hinge down and attach screws.

